


Operation & Maintenance Manual

Place this manual with valve or person responsible for maintenance of the valve

Part List

1. Isolation Valve
2. Y-Strainer
3. Orifice (restriction fitting)
4. Solenoid Valve
5. Pilot (Model PRP)
6. Flow Control (FC4)



Model C/CA/CF/CFA 105 & 106-Pressure Reducing Valve with Solenoid Override

YOUR PRODUCT INFORMATION:

Model Number: _____

Date: _____

Serial Number: _____

Valve Size: _____

Factory PRP Preset: _____ **psi**

High Quality Valves Built to Last...



15 PRUYNS ISLAND
 GLENS FALLS, NY 12801
 800-833-2040 * 518-761-9797 * Fax: 518-761-9798
 Outside U.S. 518-761-9799
 worldwideweb://www.flomatic.com * e-mail: flomatic@flomatic.com

PRESSURE REDUCING VALVE with SOLENOID OVERRIDE

The Model C/CA/CF/CFA 105 Pressure Reducing Valve with Solenoid Override permits flow and provides pressure reduction when the two-way normally open solenoid control is de-energized. Energizing the solenoid control closes the valve.

The Model C/CA/CF/CFA 106 Pressure Reducing Valve with Solenoid Override permits flow and provides pressure reduction when the two-way normally closed solenoid control is energized. De-energizing the solenoid control closes the valve.

SHIPMENT:

When shipped, controls are usually mounted on the main valve. If control sub-assemblies are shipped separately, all connections are tagged to insure correct assembly.

INSTALLATION:

1. Flush the pipeline before inserting the valve.
2. **Exercise caution to prevent dirt/debris from entering valve and control piping.**
3. Install the valve with the "arrow" on body pointing in the direction of flow.
4. Attach sub-assemblies to main valve if necessary.
5. Wire solenoid valve to control system.
6. Allow enough clearance above valve for removal of diaphragm assembly.

START-UP:

1. Install pressure gauges to inlet and outlet (optional).
2. Open both isolation valves on the control assembly.
3. Open 1/4" air bleeder at the top of the valve.
4. Open main line shut-off valve (usually a gate or butterfly valve) on the outlet side of the main valve about 1/4 open.
5. Slowly open main line shut-off valve on the inlet side.
6. Close 1/4" air bleeder when **all air has been removed** from valve cover.
7. Slowly open the main line shut-off valve on the outlet side the remainder of the way.
8. If the outlet pressure requires adjustment, turn the adjusting screw of the pilot valve counter clockwise to decrease or clockwise to increase downstream pressure. Fluid must be flowing through valve to make pilot adjustments.

CAUTION: any adjustment should be done slowly.

OPERATION:

The Models C/CA/CF/CFA 105 & 106 Pressure Reducing Valve with Solenoid Override controls and maintains a preset, reduced downstream (outlet) pressure by causing the main valve diaphragm assembly to throttle and sustain the desired reduced pressure regardless of variations in demand and upstream (inlet) pressure. The throttled position of the main valve diaphragm assembly is controlled by an adjustable pilot valve operating in conjunction with an orifice (or needle valve).

The PRP senses the downstream (outlet) pressure and reacts immediately to reposition the diaphragm assembly as the outlet pressure tends to increase or decrease with varying flow demand. The PRP diaphragm will automatically sense changes in the flow of the system as it continuously controls the main valve to throttle or to open and maintain the desired, preset reduced outlet pressure.

The solenoid override allows the control valve to fully close when the normally open solenoid is energized (C/CA/CF/CFA 105) or the normally closed solenoid is de-energized (C/CA/CF/CFA 106).

TROUBLE SHOOTING GUIDE

Problem: Valve opens and will not close resulting in excessive outlet pressure	
<p>Cause:</p> <ol style="list-style-type: none"> 1. Main valve is air bound. 2. Indicator stuffing box or sight glass is leaking (if equipped). 3. Ruptured diaphragm in PRP, evidenced by leak from vent hole in spring chamber. 4. Fouled orifice (or needle valve). 5. Fouled Y-strainer. 6. Damaged PRP valve seat. 7. Ruptured diaphragm in main valve. 8. Sticks or stones lodged under seat of main valve. 9. Worn seat packing and/or seat ring in main valve. 10. Incorrect adjustment of PRP (set too high). 11. Leakage from one or more fittings in the controls. 12. Damaged O-ring stem seal. 	<p>Solution:</p> <ol style="list-style-type: none"> 1. Open ¼" air bleeder located on top cover of valve to release air. Close when all air has been removed and water flows freely. 2. Tighten packing nut or replace packing seals. 3. Replace PRP diaphragm. 4. Remove and clean orifice, or open needle valve wide (counter clockwise) to flush seat. Return to original setting after 4 or 5 seconds. 5. Disassemble, clean or replace screen. 6. Disassemble, clean and replace damaged parts. 7. Disassemble and replace diaphragm. 8. Disassemble & remove. Replace damaged parts. 9. Disassemble and replace damaged parts. 10. Turn adjusting screw counter clockwise slowly until valve resumes control and the desired outlet pressure is obtained. 11. Tighten or replace fitting. 12. Disassemble and replace O-ring.
Problem: Valve is closed and will not open	
<ol style="list-style-type: none"> 1. Incorrect adjustment of PRP (set too low). 2. Needle valve (if installed) open too far. 3. Isolation valve at the outlet side is closed. 4. Fouled PRP valve. 5. Worn or eroded orifice (or needle valve seat). 6. Solenoid valve is closed. 	<ol style="list-style-type: none"> 1. Turn PRP adjusting screw clockwise slowly until the valve opens and the desired outlet pressure is obtained. 2. Turn adjusting cap clockwise slowly until valve opens and reduced outlet pressure is observed. Lock in position. 3. Open isolation valve. 4. Disassemble and clean, replace seat ring/packing if necessary. 5. Replace orifice (or needle valve). 6. Check solenoid valve control system to determine cause of valve closure.
Problem: Valve hunts or chatters.	
<ol style="list-style-type: none"> 1. Valve is oversized. 2. Flow control valve (or needle valve at the outlet side) is out of adjustment or may be clogged with debris. 3. PRP seat packing is damaged. 	<ol style="list-style-type: none"> 1. Install a smaller pressure reducing valve in a bypass around the oversized valve to handle low flows and provide better control. 2. Slowly turn adjusting cap counter clockwise until the outlet pressure becomes steady and/or remove to inspect for debris. 3. Replace seat packing
Test To Isolate Source Of Problem (After visual inspection of external leaks)	
<ol style="list-style-type: none"> 1. With the main line gate valves open and the control valve pressurized, close the control isolation valve at the outlet side of the PRP control. THE MAIN VALVE SHOULD CLOSE. If the valve remains fully open the source of the problem could be: <i>(A) fouled orifice or needle; (B) fouled Y-strainer; (C) control isolation valve at inlet is closed; (D) ruptured main valve diaphragm.</i> If the valve is partially closed the source of the problem could be: <i>(A) damaged main valve seat packing or seat ring; (B) debris under seat; (C) main valve is air-bound; (D) damaged stem O-ring.</i> If the valve closes fully, the source of the problem could be: <i>(A) PRP out of adjustment; (B) damaged PRP stem or seat ring; (C) partially fouled Y-strainer or needle valve.</i> 2. With the main line gate valves open and the control valve pressurized, close both isolation valves and open the ¼" air bleeder to release water out of the power chamber above the diaphragm of the control valve. Water will flow from the air bleeder as the valve moves to the full open position. If water continues to flow, the source of the problem could be: <i>(A) damaged main valve diaphragm or stem seal O-ring; (B) loose locknut.</i> 	